RISK OF DEATH, INJURY, IRREPARABLE SYSTEM DAMAGE

YOU MUST NOT OPERATE THE SYSTEM UNLESS YOU HAVE RECEIVED FULL TRAINING AND YOUR TRAINING HAS BEEN SIGNED OFF IN THE EcoRIG HANDOVER DOCUMENT – if in doubt consult your manager

This is a Quick Refresher Reference…. if in doubt ALWAYS refer back to the EcoRIG handover document

Minimum 2 people operation - One must always be watching whilst the system is in motion

Initial Checklist

Fused spur switched on, **Clear area** to work in, **Clear descent** area - persons & obstructions, **Clear line** of sight - remote user uninterrupted view of media descent

EcoRIG remote Operation

One press of the remote's **DOWN button** will bring the graphic media down in a continuous operation until the lower "stop" is reached or the **STOP button** is pressed. One press of the **UP button** will send the graphic media up until the upper "stop" is reached or the stop button is pressed.

Changing a graphic image

If you can reach the lower rail safely - remove an end cap and slide out the bottom graphic rail or lower the system until you can do so safely.

Your partner now lowers the system (**DOWN** button) while you quickly roll up the graphic media as it is being lowered until the top rail is in your arms (Safe Working Height **SWH**) whereupon your partner brings the system to a halt by pressing the **STOP** button.

Your partner releases the top graphic rail by unclipping the snap hooks from the 'U' bolts. He then removes an end cap and slides the rail off the old graphic.

Slide the new graphic into the top rail, replace the end cap, re attach the snap hooks and **check all is secure**. With the new rolled graphic cradled in your arms your partner raises the system (**UP** button) until the lower edge of the graphic is to hand and **STOP**s the system. Slide on the lower graphic rail & replace the end cap. The **UP** button will now stop the graphic media automatically at the upper limit.

The task is not finished until the paperwork is done

It is **IMPERATIVE** that you carry out 'visual in service checks' during the operation, complete the 'Staff Operation Record', switch off the fused spur and return the remote control & Allen Key to secure storage